

NOTES:

- 1. INSTALL W.H.C. 3.5 FT. MINIMUM BELOW EXISTING GRADE UNLESS OTHERWISE SHOWN OR DIRECTED BY THE ENGINEER.
- 2. PLACE A BRICK UNDER THE CURB STOP AND CURB BOX FOR STABILITY.
- 3. END OF W.H.C. AT PROPERTY LINE SHALL BE 4'-0" BELOW FINISHED GRADE UNLESS OTHERWISE SHOWN OR DIRECTED BY THE ENGINEER.
- 4. CORPORATION STOP TO BE LEFT OPEN, CURB STOP CLOSED.
- 5. FOR CURB STOP INSTALLATION ON A 1 1/2" AND 2" WATER HOUSE CONNECTION USE STANDARD VALVE BOX AND WOOD SUPPORT PER DETAIL W/2.04. SEE DETAIL W/3.00 (IF LOCATED IN A TRAFFIC OR PAVED AREA-COMMERCIAL ONLY).



STANDARD DETAIL

1", 1 1/2" & 2" WATER HOUSE CONNECTION FOR EXISTING INSIDE METERS "K" COPPER TUBING W 2.00

REVISIONS: JUNE 1995 SEPTEMBER 2022