


NOTES:

1. BACKFLOW PREVENTER(S) FOR WATER FIRE SPRINKLER SYSTEMS SHALL BE ASSE 1015
2. BACKFLOW PREVENTER(S) FOR DOMESTIC SHALL BE ASSE 1013 OR ASSE 1015, DEPENDING ON THE HAZARD LEVEL. FOR ASSE 1013, A DRAIN IS REQUIRED AND SHALL BE SIZED ACCORDINGLY.
3. BACKFLOW PREVENTER(S) FOR IRRIGATION SYSTEMS SHALL BE ASSE 1013. CONNECTION FOR IRRIGATION SYSTEMS MUST BE TAKEN FROM THE DOMESTIC LINE AFTER METER/ BACKFLOW PREVENTER(S).
4. LINE 2" AND BELOW IS CURB STOP, ANYTHING 2" AND ABOVE IS GATE VALVE.



CHARLES COUNTY GOVERNMENT

DEPARTMENT OF PLANNING & GROWTH MANAGEMENT

APPROVED: Raymond N. Shumaker, Jr. Oct 5, 2022

CHIEF OF CODES, PERMITS, & INSPECTION SERVICES DATE
J. B. Bill Oct 5, 2022
 PROFESSIONAL ENGINEER DATE

STANDARD DETAIL

SPRINKLER & DOMESTIC SYSTEM CONNECTION
 COMMERCIAL/ INDUSTRIAL

W

1.01

REVISIONS:

JUNE 1995

SEPTEMBER 2022